

PowerWise Hardware Diagram

inDAC - 1-Wire Sensor Wiring Diagram



PowerWise
124 Main Street
Bucksport, ME 04416

- I. PowerWise recommends using CAT5 or better with one twisted pair for the 1-Wire signal and ground
- II. The trunk wire should not be spliced by cutting. If splices are required, they should be 5 feet or more apart on the trunk.
- III. For the three-wire temperature sensors, connect red and black leads together and attach to GND
- IV. If the inDAC is powered by the inGate, do not power the inDAC with the second power supply

