


PowerWise inGate and PowerScout 3 HD Wiring Diagram



ETHERNET

STATUS

SHIELD

PWR -


A- (RS485)

B+ (RS485)

PWR + *

RESET

PWR*



* DC power terminals are interconnected. Do not connect to multiple power sources.